

## ***FAVORITES***

### **Create Favorite Lists:**

There are 8 pre-defined favorite lists named: Favorite1, Favorite2, etc.

1. Press Menu. Arrow down to 'My Settings' and then arrow right to 'Favorite Channels'. Press OK.
2. With your Favorite list highlighted arrow right to move to the channel list. Channels included in the Favorite list are marked with an X. Using the Arrow buttons move through the channels and press OK to add or remove a channel to your favorite list. Or, type in a channel using the number keys.
3. When done, press the Red button to save your changes.

### **Using Favorite Lists:**

1. Press FAV. By default, your list is 'All' channels.
2. Arrow right/left to choose a Favorite list. If you press Exit with a Favorite list selected, you will be in Favorites mode using that list.
3. Use either the Channel Up/Down button or the Arrow buttons to move between channels in a list. Or, use the number keys to select a channel. The 'zapper bar' shows the name of the active favorite list.
4. To leave Favorite mode, press FAV. Arrow right/left to select 'All' and press 'Exit'.

## ***PARENTAL CONTROLS***

There are two ways to use Parental Controls:

### **Set Program Rating Limits:**

To control the types of programming that can be viewed, you may set program limits based on motion-picture ratings (G, PG, R, etc.) or TV ratings (TV-G, TV-14, etc.) using the Parental Rating option in My Settings. If you attempt to tune to a channel that is airing a program with a rating at or above your rating limit, you must enter a PIN to view the program.

### **Set Locked Channels:**

You can lock entire channels via the Channel Locks option in My Settings so that they require a PIN to view programming. You may prevent locked channels from showing in the channel guide via the General Settings (locked channels would still be accessible using the number keys).

## ***REMINDERS***

### **Set Reminders:**

While viewing the guide, highlight the program where you want a reminder and press OK.

# **Remote Control Guide**



# Controlling The Remote

**TV, AUD, DVD, VCR, STB**  
Use one remote to control multiple devices.

**Setup**  
Use for programming sequences of devices controlled by the remote.

**REW, PLAY, FFWD, STOP, PAUSE**  
In STB mode, these control the DVR/PVR functions. In other modes, these can control a VCR, DVD Player or PVR.

**Menu**  
Displays applications including the configuration menu.

**Guide**  
Opens the Interactive Program Guide.

**Day +/-**  
Jump ahead or back one day in the Interactive Program Guide.

**Red, Green, Yellow, Blue**  
Access additional features on your set-top box.

**Vol +/-**  
Raise or lower the volume.

**Mute**  
Turn the sound off or on.

**Input**  
In TV control mode, would change the input of the device you are controlling.



**Power**  
Turn on/off a selected device.

**Live**  
Return to watching live TV.

**List\***  
Display a list of recorded shows on your PVR/DVR set-top box.

**Info**  
Display the current channel and program information. Press again for more detail.

**Arrow Keys/OK**  
Navigate and select onscreen choices.

**Exit**  
Exit the current screen.

**Page +/-**  
Page up or down in menu screens & Interactive Program Guide.

**Channel +/-**  
Changes to the next higher or lower channel.

**On Demand\***  
Access video on demand services.

**Last**  
Recall the last channel you were watching.

**FAV**  
View your favorite channels.

**Number Keys (0-9)**  
Directly select a channel.

\*If Available



## WHAT'S ON TV?

There's more than one way to see what's showing on TV.

### Info Button:

Press Info once for a brief description of the program you are viewing. Press Info again for more details.

### OK Button:

Press OK to show the 'zapper bar'. You'll see what's showing now and what's on next.

### Guide Button:

This is the most comprehensive view of what's on. Go ahead and page through...you're bound to find something to watch.