

**Programming remote to control TV (searching for your code)**

Turn on your TV

Press TV on the remote control

Press and hold setup until TV button blinks twice

Type 9 9 1

Hit Ch UP until your TV turns off

Press setup to lock in code

Press power again to verify TV turns back on